

MANUALE DI ISTRUZIONI
ART. 13/00205-00**Alimentatore 12V****ISTRUZIONI OPERATIVE**

Si prega di leggere attentamente queste istruzioni per un uso appropriato e sicuro.

Connessione:

1. Connettere inizialmente il cavo di alimentazione e successivamente inserire la spina CA nella presa sul muro. La spia LED si accenderà immediatamente..
2. Collegare il carico dell'apparecchiatura nella presa accendisigari da 12V.
3. Accendere l'apparecchio.
4. Non utilizzare apparecchi che richiedano correnti superiori a 5A.

Specifiche:

Ingresso: 100-240V 50/60Hz

Uscita: 12V CC 5A, max. 60VA

AVVERTENZE:

1. Scollegare sempre l'alimentatore dalla presa di alimentazione a muro quando non viene utilizzato.
2. Tenere a portata di mano l'alimentatore e l'apparecchio ad esso collegato in modo che sia facilmente scollegabile nel caso di eventi imprevisti.
3. Assicurarsi che nessun oggetto estraneo entri in contatto con la presa 12V e possa cortocircuitare i terminali in uscita.
4. Assicurarsi che il carico dell'apparecchiatura collegata all'alimentatore non superi la potenza massima in uscita.
5. Assicurarsi che la tensione di uscita e la potenza dell'alimentatore siano compatibili con quelle dell'apparecchio ad esso collegato. L'apparecchio collegato potrebbe danneggiarsi se soggetto a correnti o tensioni eccessive.
6. Non tentare di aprire l'unità di alimentazione.
7. Scollegatelo dalla rete elettrica quando non è in uso.

**Informazione agli utenti ex art. 26 D.Lgs. 49/2014**

Il simbolo riportato sull'apparecchiatura (Allegato IX D.Lgs. 49/2014) indica che il rifiuto deve essere oggetto di "raccolta separata" e che è stato immesso sul mercato, in Italia, dopo il 31/12/2010.

Pertanto, l'utente dovrà conferire (o far conferire) il rifiuto ai centri di raccolta differenziata predisposti dalle amministrazioni locali, oppure consegnarlo al rivenditore contro acquisto di una nuova apparecchiatura di tipo equivalente.

L'utente ha dunque un ruolo attivo: la raccolta differenziata del rifiuto e le successive operazioni di trattamento, recupero e smaltimento favoriscono la produzione di apparecchiature con materiali riciclati e limitano gli effetti negativi sull'ambiente e sulla salute eventualmente causati da una gestione impropria del rifiuto.

Nel caso di RAEE di piccolissime dimensioni (<25 cm), l'utente ha diritto al conferimento gratuito, senza obbligo di contestuale acquisto, ai distributori al dettaglio la cui superficie di vendita specializzata eccede i 400 mq.

IMPORTATO E DISTRIBUITO DA
ELCART DISTRIBUTION SPA
Via Michelangelo Buonarroti, 46
20093 COLOGNO MONZESE (MI)
ITALY
www.elcart.com - info@elcart.it



Made in China

INSTRUCTION MANUAL ART. 13/00205-00

12V Power Supply

OPERATING INSTRUCTIONS

For proper and safe operations, please read these instructions carefully before use.

Connection:

1. Connect the power cord to the power supply first and then insert AC plug into your wall socket. The LED indicator will light instantly.
2. Plug the load appliance into the power supply unit's 12V car socket.
3. Switch on your appliance.
4. Do not use the power supply unit with appliances requiring currents of more than 5A.

Specifications:

Input: 100-240V 50/60Hz

Output: 12V DC 5A, max. 60VA

CAUTION :

1. Always unplug the power supply unit from the wall socket when it is not in use.
2. Always keep the power supply unit close to the connected appliance and accessible so that it can easily be disconnected if something unexpected should happen.
3. Make sure that no foreign objects find their way into the 12V socket and short circuit the output terminals.
4. Make sure that the load appliances connected to the power supply unit do not exceed the maximum output power rating.
5. Make sure that the output voltage and power ratings of power supply unit are compatible with the appliance which is to be connected. The connected appliance could be damaged if it subjected to excessive current or voltage.
6. Do not attempt to open the power supply unit.
7. Remove from mains when not in use.



User information ex art. 26 D. 49/2014

The symbol labelled on the appliance (Annex IX D. 49/2014) indicates that the rubbish is subject to "separate collection" and it has been placed on the Italian market after the December 31, 2010.

The user must therefore assign or (have collected) the rubbish to a treatment facility according to indications by the local administration, or hand it over to the reseller in exchange for an equivalent new product. The separate collection of the rubbish and the subsequent treatment, recycling and disposal operations encourage the production of appliances made with recycled materials and reduce negative effects on health and the environment caused by improper treatment of rubbish.

In the case of very small WEEE (no external dimension more than 25 cm), the user is eligible to get free of charge assignation to retail shops with sales areas relating to EEE of at least 400 m².



IMPORTED AND DISTRIBUTED BY:
ELCART DISTRIBUTION SPA
Via Michelangelo Buonarroti, 46
20093 COLOGNO MONZESE (MI)
ITALY
www.elcart.com - info@elcart.it

Made in China

ELCART DISTRIBUTION SPA via Michelangelo Buonarroti, 46 - 20093 Cologno Monzese (Milano) ITALY
Tel. +39 02.25117310 Fax +39 02.25117610 sito internet: www.elcart.com e-mail: tecnico@elcart.it

La divulgazione dei dati contenuti in questa scheda è da ritenersi un servizio puramente informativo e non costituisce alcun vincolo da parte della Elcart in merito a prestazioni ed utilizzo del prodotto.
The divulgation of data contained on this technical sheet are exclusively for informational reasons and establish no link on behalf of Elcart regard to the performances and the use of the product.
La divulgación de los datos contenidos en esta ficha son un servicio unicamente informativo y no constituyen ningun vínculo de parte de Elcart respecto a las prestaciones y uso del producto.